

mini V3 upgarde guide

CSD No:


Product / Project:

Common upgrade tools


<u>Version</u>	<u>Date</u>	<u>ECO#</u>	<u>Description</u>	<u>Reporter</u>	<u>Responsible</u>
V1.18	20250731	0	release	蔡智平	颜韦玲

Online upgrade guide

(1)When the device is connected to the Internet, trigger "SETTING" in the main menu and select Update to enter the operation interface. The control characters on the right side will display "New Version Available". Please trigger the control and follow the instructions step by step. After the download is completed, the device will automatically upgrade. Please wait patiently and do not power off and restart in the middle of the process.



(1)



(2)

地址: 厦门市湖里区留学人员创业园伟业楼 S504, 603, 604

电话: 4008 592 315

传真: +86 592 5771202

email: rgblinkcs@gmail.com

http:// www.rgblink.cn



RGBlink